

Crystal USB Cable Install Instructions:

The USB cable that has been supplied needs to have its drivers installed onto your computer.

- Plug the cable into a spare USB port and plug the other end into your XP2i.
- Turn on the XP2i.
- Your computer will ask you to "Insert Disk."
- Click on "OK" and then browse through the supplied disk or the Zipped file that you have downloaded.
- The first folder you need to open is Called " **Crystal 3667 USB,**" once you have opened this click on the folder that suits your system. I.E. "Win 2000-Xp-Vista" if your system utilises Windows 2000, XP or Vista.
- You then need to open folder "**i386**" and click on file "**ftdibus.sys**"
- Then click "ok" "open", and then "continue anyway."
- You will then need to repeat the above process.
- You should now get a pop up box saying "Found new hardware" and then another saying "New Hardware is ready to use."
- Open up your datalogger software and check communication. Make sure the gauge is on.